




PARTS LIST FOR MODEL SG5000/SG6000



KEY NO.	DESCRIPTION	PART NO.
1	Housing (5000SG)	001 5000SG
	Housing (6000SG)	001 6000SG
4	A/R Dog	004 5000SG
5	A/R Dog Spring	005 5000SG
6	Retaining Clip	006 5000SG
8	Main Gear	008 5000SG
8A	Shim	008A5000SG
10	A/R Holder	010 5000SG
11	Bushing	011 5000SG
12	A/R Bushing Spring	012 5000SG
15	Handle Assembly	015 5000SG
19	Pinion	019 5000SG
19A	Pinion Bushing	019A5000SG
20	Lower Pinion Ball Bearing	020 5000SG
20A	Upper Pinion Ball Bearing	020A5000SG
20B	Housing Ball Bearing	020B5000SG
20C	Housing Cover Ball Bearing	020C5000SG
21	Bearing Retainer	021 5000SG
21A	Bearing Retainer Screw (3 req.)	021A5000SG
21B	Collar	021B5000SG
22	Bail Pivot Cover Screw	022 5000SG
24	Bail Wire Assembly (5000SG)	024 5000SG
	Bail Wire Assembly (6000SG)	024 6000SG
27	Rotor (5000SG)	027 5000SG
	Rotor (6000SG)	027 6000SG
27A	Bail Pivot Cover	027A5000SG
28	Trip Lever (5000SG)	028 5000SG
	Trip Lever (6000SG)	028 6000SG
31	Bail Arm Screw	031 5000SG
31A	Bail Cam Screw	031A5000SG
32	Bail Spring	032 5000SG
34	Bail Arm	034 5000SG
34C	Pivot Arm	034C5000SG
35	Line Roller	035 3000SG
35A	Line Roller Bearing	035A3000SG
36	Bail Stud Screw	036 5000SG
38	Rotor Nut	038 5000SG
38A	Rotor Locking Plate Screw	038A5000SG
39	Spool Shaft (5000SG)	039 5000SG
	Spool Shaft (6000SG)	039 6000SG
43	Crosswind Block	043 5000SG
43A	Crosswind Block Plate	043A5000SG
43B	Crosswind Block Plate Screw (2 req.)	043B5000SG
44	Crosswind Block Screw (2 req.)	044 5000SG
45	Housing Cover (5000SG)	045 5000SG
	Housing Cover (6000SG)	045 6000SG
46	Housing Cover Screw (3 req.)	046 5000SG
46A	Housing Cover Screw A	046A3000SG
46B	Housing Cover Washer (3 req.)	046B5000SG
47	Spool Assembly (5000SG)	047 5000SG
	Spool Assembly (6000SG)	047 6000SG
51	Retaining Spacer	051 5000SG
51A	Retaining Screw (2 req.)	051A3000SG
52	Drag Knob	052 5000SG
56	Drag Washer (5 req.)	056 5000SG
57	Keyed Washer (3 req.)	057 5000SG
58	Eared Washer (2 req.)	058 5000SG
60	Thrust Washer	060 5000SG
95B	Rotor Locking Plate	095B5000SG
98C	Clutch/Sleeve Assembly	098C5000SG
132	Roller Washer	132 5000SG
132A	Line Roller Washer (2 req.)	132A3000SG
226	Rear Cover	226 5000SG
226A	Rear Cover Screw	226A3000SG
231	Crosswind Gear	231 5000SG
233	Bearing Cover	233 5000SG