


Abu Garcia CARDINAL S20R/S30R/S40R



ABU SP Cardinal S20R/S30R/S40R 00

PARTS LIST OF CARDINAL S20R/S30R/S40R

ITEM#	DESCRIPTION	PART#(S20R)	PART#(S30R)	PART#(S40R)	ITEM#	DESCRIPTION	PART#(S20R)	PART#(S30R)	PART#(S40R)
1	Spool	1302722	1302732	1302742	37	Clutch switch	1280986	1280986	1280986
1	Spare spool	1302723	1302733	1302743	38	Drive gear	1302725	1302725	1302725
2	Bolt	1208221	1208221	1208221	39	Body cover	1302726	1302736	1302746
3	Main shaft	1302724	1302724	1302744	40	Click plate	1208229	1208229	1208229
4	Bail arm screw(2req)	1126379	1126379	1126379	41	Spring	1208230	1208230	1208230
5	Bail holder	1280984	1280984	1280984	42	Washer	1117948	1117948	1117948
6	O-ring	1252708	1252708	1252708	43	Reduction gear	1252732	1252732	1252732
7	E clip	1252707	1252707	1252707	44	Body	1302727	1302737	1302747
8	Bushing(2req)	1188261	1188261	1188261	45	Washer	1092781	1092781	1092781
9	Rotor	1279726	1279743	1279749	46	Handle screw	1279737	1279737	1279737
10	Rotor nut	1085273	1085273	1085273	47	Slider retainer	1126332	1126332	1126332
11	Nut set Screw	1126258	1126258	1126258	48	Screw (2req)	1188428	1188428	1188428
12	Line roller screw	1126261	1126261	1126261	49	Slider screw	1085401	1085401	1085401
13	Bail arm	1280985	1280985	1280985	50	Retainer ring	1101972	1101972	1101972
14	Brass bushing	1279727	1279727	1279727	51	Slider	1302728	1302728	1302748
15	Line roller	1252705	1252705	1252705	52	Rear cover	1302739	1302739	1302749
16	Pom bushing	1252756	1252756	1252756	53	Oscillation gear	1252730	1252730	1253720
17	Brass bushing	1252755	1252755	1252755	54	Bushing	1108938	1108938	1108938
18	Bail assy	1279728	1279744	1279750	55	Screw (2req)	1119026	1119026	1119026
19	Screw(3req)	1125962	1125962	1125962	56	Screw (2req)	1117984	1117984	1117984
20	Bail holder cover	1279729	1279729	1279751	57	Handle assy	1279740	1279740	1279740
21	Bail arm cover	1279730	1279730	1279752	58	Retainer plate	1224008	1224008	1224008
22	Trip spring	1119106	1119106	1119106	59	Drag house	1224009	1224009	1224009
23	Bail slider	1126272	1126272	1126272	60	Washer	1085405	1085405	1085405
24	Trip linkage	1252713	1252713	1252713	61	Drag gear	1101975	1101975	1101975
25	Trip bar	1279731	1279745	1279753	62	Washer(3req)	1085407	1085407	1085407
26	Screw(3req)	1092844	1092844	1092845	63	Eared washer	1085408	1085408	1085408
27	Pinion cover	1252715	1252715	1252715	64	Key washer	1085409	1085409	1085409
28	Washer(2req)	1114764	1114764	1114764	65	Eared washer	1085410	1085410	1085410
29	Ball bearing (3req)	1252717	1252717	1252717	66	Drag spring	1224010	1224010	1224010
30	Bearing holder	1280475	1280475	1280475	67	Click house	1224011	1224011	1224011
31	Clutch spring	1252716	1252716	1252716	68	Drag knob	1302730	1302730	1302730
32	Clutch assy	1252719	1252719	1252719	69	Ring	1085414	1085414	1085414
33	Pinion	1279732	1279732	1279732	70	Plastic ring	1302731	1302731	1302731
34	Screw	1141435	1141435	1141435	71	Spring	1131609	1131609	1131609
35	Bushing	1279733	1279733	1279733	72	Click shaft	1131610	1131610	1131610
36	Clutch switch spring	1252722	1252722	1252722					